

Tunebug Shake Quick Set Manual

Connect with  **Bluetooth**

1. Turn On/Off Power



!Fully Charge Before Operating!

POWER ON

Place fingers over Touch Sensitive Areas indicated for 2 seconds. Shake will flash **Green** then go **Blue**.

POWER OFF

Place fingers over Touch Sensitive Areas indicated for 5 seconds, Shake will flash **Red** then turn off.

Charging

Turn off Power before charging.

2. Connect & Play

Set Shake to Pair

1. From Off, place fingers over designated controls for 4 sec. until Shake flashes **Red/Blue**.



Connect to Bluetooth

1. Go to your audio device settings and enable the **Bluetooth** function.
2. Once your audio device identifies the "TUNEBUG SHAKE", accept the connection.
3. Some devices require a security code. Type "0000".

Your Now Connected & Ready To Play



3. Adjust Volume



VOLUME UP

Press and hold finger over right Control Area to increase Volume. Shake will flash **Green** at each increase.



VOLUME DOWN

Press and hold finger over left Control Area to decrease Volume. Shake will flash **Green** at each decrease.



www.tunebug.com
408.792.7022

Tunebug Shake Quick Set Manual

Connect with an Audio Cable

1. Turn On/Off Power



!Fully Charge Before Operating!

POWER ON

Place fingers over Touch Sensitive Areas indicated for 2 seconds. Shake will flash **Green** then go **Blue**.

POWER OFF

Place fingers over Touch Sensitive Areas indicated for 5 seconds, Shake will flash **Red** then turn off.

Charging

Turn off Power before charging.

2. Connect Cable



Plug In Audio Cable

Plug in Audio Cable into Shake and Audio Device.
(If Audio Device has **Bluetooth** you must first disable **Bluetooth** before playing music through cable).

PLAY YOUR TUNES

3. Adjust Volume



VOLUME UP

Press and hold finger over right Control Area to increase Volume. Shake will flash **Green** at each increase.



VOLUME DOWN

Press and hold finger over left Control Area to decrease Volume. Shake will flash **Green** at each decrease.



www.tunebug.com
408.792.7022